



UNIPRO
THE ORIGINAL LAPTIMER

setup	timer lap		
023405340131501		split	
10351343540303051			
1031313035103		func	
10131351351354666			
43464687167			
176767676871313			
786687138138731			
7167186778			
16871776878167			
871671681			

To update the UniGo 7006 with USB cable do the following:

1. Save the new firmware on your computer
2. Turn on the UniGo
3. Connect the USB cable between the UniGo and your computer.
4. Copy the new firmware version into the firmware folder on the “UniGo” drive.
5. Disconnect the USB cable, and just after press the OK button
6. When UniGo turn off, and on again the new firmware is installed.

To update the UniGo 7006 with the USB flash key do the following:

1. Make a folder called Firmware on the USB flash key
2. Copy the bin file (new firmware) into this folder
3. Connect the flash key, and select Firmware update from the USB menu and press ok
4. After the file is downloaded to the UniGo, remove the flash key, and just after press the OK button
5. When UniGo turn off, and on again the new firmware is installed.